Item #
Model #D6081-GZ

USE AND CARE GUIDE

10 Ft. x 12 Ft. GAZEBO WITH MOSQUITO NETTING



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this gazebo. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents 2
Safety Information 2
Warranty 2
One Year Frame and Fabric Limited Warranty..... 2
What Is Covered 2
What Is Not Covered 2
Pre-Assembly 3
Planning Assembly.....3
Hardware Included.....3
Package Contents.....4
Assembly 5
Care and Cleaning.....8

Safety Information

WARNING: Keep all flame and heat sources away from this tent fabric. This tent is made with fabric that meets CPAI-84 specification for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistance properties ineffective.

WARNING: This Gazebo is NOT a permanent structure and is designed for sunshade and privacy and must be used under normal weather conditions. We recommend removal of the fabric canopy in windy conditions as gazebos catch wind similar to umbrellas. You must however completely disassemble the unit prior to any severe weather conditions such as thunderstorm, hurricane, and/or heavy wind and rain. Failure to remove the fabric canopy or disassemble the unit will cause the gazebo to have structure damage or even structural collapse.

CAUTION: Always install on level ground utilizing tie down cords and ground stakes. Do not permanently anchor the unit to a wood deck or concrete surface.

CAUTION: Gazebo fabrics are water resistant but not water proof and may leak during precipitation. Fabrics will fade from direct exposure to sunlight.

CAUTION: Keep all children and pets away from the assembly area.
Begin assembly not less than 6 ft. from any obstruction such as a fence, garage, house, overhanging branches, clothes line or electrical wires. Some parts may contain sharp edges, wear protective gloves if necessary. At least two or more people are recommended for safe assembly.

CAUTION: The maximum weight that the vent hub can withstand is 20 lbs.

Warranty

THIS IS A RESIDENTIAL WARRANTY AND DOES NOT APPLY FOR COMMERCIAL USE

ONE YEAR FRAME AND FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty.

We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For a copy of our full limited warranty, please contact our customer service team below.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.hamptonbay.com

Pre-Assembly

PLANNING ASSEMBLY

PLEASE READ COMPLETE INSTRUCTION MANUAL PRIOR TO ASSEMBLY!

Identify all parts packed in the carton against the parts list. Remove all protective materials and place the parts in a non-abrasive surface to avoid scratching.

NOTE: At least two or more persons will be required to complete the assembly of this product.

HARDWARE INCLUDED

NOTE: Except bolts, other hardware is not shown to actual size.



Part	Description	Quantity
AA	M6*30 Hex bolt	8
BB	M6*45 Hex bolt	16
CC	M6*50 Hex bolt	8
DD	M6 Nut	32
EE	Wrench	2
FF	Stake	8

Pre-Assembly (continued)

PACKAGE CONTENTS

NOTE: The nettings have already been zipped from four to two pieces in the packaging. There will be sticked part# on all package parts.


A


B


C

D

E

F

G

H

I

J

K

L

M


N

Part	Description	Quantity
A	Side panel A	4
B	Side panel B	4
C	Vent hub	1
D	Long roof tube	4
E	Short roof tube	4
F	Long roof support tube	2
G	Short roof support tube	2
H	Long lintel	4
I	Short lintel	4
J	Lintel connector	4
K	Triangle fixed plate	4
L	Vent cover	1
M	Main canopy	1
N	Mosquito netting	4

Assembly

1 Attaching side panels

□ Place the side panel (A) and side panel (B) on a soft, flat, non-abrasive surface. Attach the side panel (A) to the side panel (B) using the hex bolts (BB) and nuts (DD). Repeat this step until the four side panels are completed.

NOTE: The hole sites on the side panel A and side panel B are different. The hole at the bottom of side panels A and B should be facing inside. Do not fully tighten!



2 Setting up the main frame

□ Connect the long lintels (H) and the short lintels (I) using lintel connectors (J). Lock the triangle fixed plates (K) on the four corners of the lintel tubes using M6*50 hex bolts (CC) and M6 nuts (DD). Fix the lintels (H&I) onto the side panels (A and B) using M6*45 hex bolts (BB) and nuts (DD).



NOTE: The push pin on the lintels (H/I) should point upwards.



Assembly (continued)

3 Assembling the roof frame

□ Snap the short side of the short roof tube (E) into each long roof tube (D). Snap the other end of the long roof tube (D), long roof support tube (F) and short roof support tube (G) into the receivers of the vent hub (C).

NOTE: The hook of the vent hub should be facing down.



4 Attaching the roof frame

□ Using a ladder, place the roof frame onto the main frame by attaching the short roof tubes (E), long roof support tubes (F) and short support tubes (G) to the lintel connectors (J) and the triangle fixed plates (K) using M6*30 hex bolts (AA) and M6 nuts (DD).

NOTE: Use at least two people for this step. Three people are strongly recommended.



Assembly (continued)

5 Attaching the main canopy and vent cover

- □ Cover the roof with the main canopy (M). Fully extend each corner of the main canopy (M) and insert the end of each roof tube (E) into the canopy pockets.
- □ From inside of the frame place the vent cover (L) over the frame. Fully extend each corner of the vent cover (L) and insert the end of each corner roof tube (D) into the pockets of the vent.
- □ Adjust each post until all posts stand upright. Make sure all are level.
- □ Hammer one ground stake (FF) through the hole in the bottom of each panel (A and B) board into soft ground to stabilize the gazebo.



6 Attaching the mosquito netting to the gazebo

- □ Attach the mosquito netting (N) to the corner first, then to the lintel tubes (H and I) with velcro. The netting should be insde of the gazebo.

NOTE: There are four velcro pieces on the 10 ft. side and ten velcro pieces on the 12 ft. side.

NOTE: The nettings have already been zipped from four to two pieces in the packaging.



Care and Cleaning

- Do not allow water to build up in frames. This will cause corrosion and possible freezing damage in cold climates.
- Use a mild soap and water for normal cleaning. Do not use janitorial or alcohol-based cleaners. Some cleaners may be marked as natural, but some ingredients may cause discoloration or have an adverse reaction to your finish.
- Rinse with clean water and dry with a soft, absorbent cloth towel.
- Treat frames with a liquid wax for maximum protection against UV rays and/or salty, damp air.
- Wash the canopy with a mild solution of soap and water, rinse thoroughly and air dry completely.

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 6 p.m., EST, Monday-Friday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.